



Zigmont Magic F/X, Inc.

Providing All Special Effects

www.effectspecialist.com

www.zigmont.com

Phone 813.689.6269

zigmont@zigmont.com

Fireworks – Propane Flames – CO2 Blasts – Confetti – Snow
Exploding Balloon Walls – Wind – Smoke Effects – Pyrotechnics

Thank you for renting a Snowmasters snow machine. Each machine needs 10 amps to run, AC cord loses 1 amp every 20 feet.

You will find the snow machine with a weather cover, once taken out of the case you will need to place the c clamp to the top yoke in order to clamp the machine of a pipe. You have a safety cable as well. You can leave this machine out in light rain, but you should run it in rain. You should have a ground fault for outdoor use.

You will need to mix the each concentrate mix with one gal distilled water for each in the bottle in back of the machine.

You will need to plug in the cable remote and make sure the blower is on Max. Use the cable remote to operate.

Make sure the hose is all the way down into the bottle.

Please remove all snow fluid from the bottles before shipping. Do not return with fluid in bottles, as this will damage the machines.

Please repack machines as they were packed. With c clamp off and to the side.

Please label the machines and they are schedule for pick up.

Please Remove all fluid before packing

Do not send fluid back or in the Gal bottle

Sending fluid back can damage the machine